



VoxBooks™
Books that Talk!

How to use

Me pehea te whakamahi

The VOX™ Reader is permanently attached to the inside of every VOX Book.

Ko te VOX™ Reader he pumau tonu ka piri ki roto o ia Pukapuka VOX.

SPEAKER	TUKUORO
POWER When the reader is on, the red and green lights will both be on.	HIKO I te wā, kua timata te mihini pānui, ka kite koe i te rama whero me te rama kakariki.
RED LIGHT Will flash when battery is low.	RAMA WHEREO Ka uira ina iti te pākahiko.
GREEN LIGHT After a 5 second boot-up, the reader will play and the green light will flash.	RAMA KAKARIKI Whai muri i te 5 tuarua o te whakaohoo, ka takaro te kaipanui, ka whiti te rama matomato.
PLAY/PAUSE If the reader is paused, both the red and green lights will light up.	PUREI/KĀTI Mehemea kua kāti te mihini pānui, ka marama i te rama whero me te rama kakariki.
VOLUME	KAHAORO
SKIP FORWARD/BACKWARD	PEKE WHAKAMUA/HOKI WHAKAMURI
EARPHONE PORT	WĀHANGA PURUTARINGA
CHARGING PORT While charging, both lights will blink. When charging is complete, both lights will be solid.	WĀHANGA HIHIKO I te wā hihiko, ka kemokemo ngā rama e rua. Ka mutu te hihiko, ka tū tonu ngā rama e rua.

