


## How to use

The VOX™ Reader is permanently attached to the inside of every VOX™ Book.



### User Controls

Adjust the volume using the + and - buttons. Move forward or back a page with the ← and → buttons.

### Listening Options

Use the built-in speaker above the control panel or attach earphones using the jack along the left side.

### Easy Charging

To recharge, simply insert the included wall charger into the earphone/charging jack and connect to a wall outlet.



VOX™ Books is proudly provided by

**library ideas®**



[www.libraryideas.com/vox-books](http://www.libraryideas.com/vox-books)




[info@libraryideas.com](mailto:info@libraryideas.com)



571.730.4300

## Guía de uso

El Lector VOX™ está permanentemente incorporado en todos los Libros VOX™.



### Controles

Ajuste el volumen con los botones + y -. Avance o retroceda una página con los botones ← y →.

### Opciones para escuchar

Utilice el altavoz incorporado sobre el panel de control o conecte auriculares en la toma del lado izquierdo.

### Carga sencilla

Para recargar, simplemente inserte el cargador de pared incluido en la toma de auriculares/carga y conéctelo al tomacorriente.