



VoxBooks™
Books that Talk!

How to use Cómo utilizar

The VOX™ Reader is permanently attached to the inside of every VOX Book.

El Lector VOX™ está permanentemente incorporado en todos los Libros VOX

SPEAKER

POWER

When the reader is on, the red and green lights will both be on.

RED LIGHT

Will flash when battery is low.

GREEN LIGHT

After a 5 second boot-up, the reader will play and the green light will flash.

PLAY/PAUSE

If the reader is paused, both the red and green lights will light up.

VOLUME

SKIP FORWARD/ BACKWARD

EARPHONE PORT

CHARGING PORT

While charging, both lights will blink. When charging is complete, both lights will be solid.

ALTAVOZ

ENCENDIDO

Cuando el lector está encendido, las luces roja y verde están encendidas.

LUZ ROJA

Destella cuando la energía de la batería es baja.

LUZ VERDE

Después del arranque de 5 segundos, el lector comienza a reproducir y la luz verde destella.

REPRODUCIR/ PAUSAR

Si el lector está en pausa, se encienden las luces roja y verde.

VOLUMEN

AVANZAR/ RETROCEDER

PUERTO PARA AURICULARES

PUERTO DE CARGA

Durante la carga, ambas luces parpadean. Cuando finaliza la carga, ambas luces permanecen encendidas.

