



VoxBooks™

Books that Talk!

How to use Comment utiliser

The VOX™ Reader is permanently attached to the inside of every VOX Book.

Le lecteur VOX™ est fixé en permanence à l'intérieur de chaque livre VOX.

SPEAKER

POWER

When the reader is on, the red and green lights will both be on.

RED LIGHT

Will flash when battery is low.

GREEN LIGHT

After a 5 second boot-up, the reader will play and the green light will flash.

PLAY/PAUSE

If the reader is paused, both the red and green lights will light up.

VOLUME

SKIP FORWARD/ BACKWARD

EARPHONE PORT

CHARGING PORT

While charging, both lights will blink. When charging is complete, both lights will be solid.

HAUT-PARLEUR

BOUTON D'ALIMENTATION

Lorsque le lecteur est allumé, les voyants rouge et vert s'allument.

FEU ROUGE

Clignote lorsque la batterie est faible.

FEU VERT

Après 5 secondes, le voyant vert continue de clignoter.

LECTURE/PAUSE

Si le lecteur est en pause, les voyants rouge et vert s'allumeront.

VOLUME

AVANCER/ EN ARRIÈRE

PORT POUR ÉCOUTEURS

PORT DE CHARGE

Pendant le chargement, les deux les lumières clignoteront. Une fois la charge terminée, les deux voyants resteront allumés.



library ideas®